


Ladies waistcoat Edit / Slim fit / Woolmix Comfort

Art no: 5011013



	Normal size (cm)	32	34	36	38	40	42	44	46	48	50	52	54
A	Chest width	85	88	91	94	98	102	106	110	114	118	122	126
B	Waist width	75	78	81	84	88	92	96	100	104	108	112	116
C	Bottom width	81	84	87	90	94	98	102	106	110	114	118	122
D	Center back length	49,5	50	50,5	51	51,5	52	52,5	53	53,5	54	54,5	55

	Long size (cm)	32L	34L	36L	38L	40L	42L	44L	46L	48L	50L	52L	54L
D	Center back length	53,5	54	54,5	55	55,5	56	56,5	57	57,5	58	58,5	59

HOW TO MEASURE

To find the right size, compare a similar garment at home with our measurements. Measure flat across the item - never around.

Chest width / Measure across the chest between the lowest point of the arm seams. Multiply with 2.

Waist width upper wear / Measure the width at the garment's narrowest point. Multiply with 2.

Waist width bottom wear / Place the garment on a flat surface with the front up and measure from side to side. Multiply with 2.

Bottom width / Measure from side to side at the bottom of the garment. Multiply with 2.

Center back length / Measure the center back from the neck seam to the end of the garment.

Sleeve length / Lay the arm flat and measure from the shoulder point to where the cuff ends.

Seat width / Place the garment on a flat surface with the front up and measure from side to side at the garment's widest point. Multiply with 2.

Thigh width / Measure straight across the width of the leg. Multiply with 2.

Inseam / Measure the inside leg from the crotch to the bottom of the trousers.

Foot width / Measure from side to side at the bottom of the trousers. Multiply with 2.

Length / Measure from the highest point of the garment to the end of the garment.

Collar length / Open the shirt and lay the collar flat. Measure from the center of the button to the outer edge of the buttonhole.